

VI.5.3D-METRIC PROGRAM FCST HCL TECHNIQUE METRIC

Purpose

Technique METRIC sets whether data are input and printed in English or metric units.

Valid values are NO (0) and YES (1).

The Global default value is NO (0).

This Technique is Universal.

Form of Input

METRIC(integer)

where integer specifies the input and print units:

0 = English
1 = metric

Example

METRIC(0)

The data will be input and printed in English units.